



30872 Huntwood Ave., Unit #6
Hayward, CA 94544
(510) 471-3026
www.billetboys.com

INSTALLATION INSTRUCTIONS

Front fender tip light:

1. Use a small screwdriver to pry the fender tip lens from the chrome surround utilizing the slot on the top of the lens. Note that both the surround and the lens are plastic so use care when prying.
2. Remove the fender tip assembly by unscrewing two screws holding it to fender. They are held by two nuts on the underside of the fender. (This hardware will not be reused.) You may have to loosen the two nuts inside the fender holding the two trim spears in order to release the chrome surround. Pull the surround straight forward to release it from the fender. Disconnect the light's wiring from the connector.
3. Drill out the two rivets holding the stock bulb holder and remove holder and wiring.
4. Insert wiring from LED circuit board through the fender tip surround and connect the plugs.
5. Before attaching circuit board to fender, slide each of the thin plastic washers under the LEDs over the holes in the circuit board.
6. Use the following sequence to attach the LED circuit board and chrome surround to the fender: The screw goes through the thin plastic washer, the circuit board, the nylon spacer, the chrome plastic fender tip surround, the fender, a flat washer, and the nyloc nut. Insert the ends of the chrome surround into the trim spears on the sides of the fender. Adjust alignment of fender tip light assembly on the fender as necessary. Tighten the nuts holding the trim spears and the circuit board. Do not over tighten screws or the circuit board may be damaged.
7. Check to see that there is at least 1/16" clearance between the circuit board and the chrome plastic fender tip surround. **Most LED failures are the result of the back of the circuit board contacting the chrome surface and shorting out the LEDs!**

If you have any questions, please feel free to contact us at (925) 362-8220.